INSPIRED BY NATURE REVOLUTIONIZED BY SUREFOOT





CONCRETE FREE FOOTING SYSTEM





SUREFOOT SYSTEMS & ACCESSORIES

THE SUREFOOT PRINCIPLE

Surefoot's engineering principles are based on a combination of shallow and deep foundation design methodology. It uses the theory of bearing capacity of a shallow foundation, plus the skin friction and toe resistance of a deep foundation in all soil types through a fully certified footing design. Micro piles are driven with a jackhammer. The footing has instant capacity and does not disturb the ground, therefore affording tremendous efficiency of time, labour, material and project cost.

Low cost, time saving, high strength & instant bearing capacity-Surefoot pile cap mimics a tree's root system through a series of steel micro piles in a battered array, resolving foundations at relatively shallow depths and efficient transfer of load and uplift forces with minimal soil disturbance.

SUREFOOT VS CONCRETE

	SUREFOOT	CONCRETE
Fixed costs	YES	NO
Excavations required	NO	YES
Dirt or spoil removal off site or relocation on site	NO	YES
Engineering impection required	NO	YES
Concrete pump required	NO	YES
Propping materials for setting up posts	NO	YES
Gravel for bottom of post holes	NO	YES
Instant bearing capacity of foundations so your works can continue same day	YES	NO
Workplace health & safety risk	LOW	HIGH
Total installation time	SHORT	LONG
Rain delays - post holes full of water	NO	YES
Number of trades and materials required to organise	2	UP TO 10
Access issues for machinery & materials	NO	YES
Environmentally friendly	YES	NO
Re establishment of landscape required	NO	YES
Adjustable in both plumb & level after your foundation is installed	YES	NO





SUREFOOT FOOTINGS ARE

- · High strength
- Simple
- · Cost effective
- · Quick to install
- · Minimal soil and site disturbance
- Recyclable and reusable
- Suitable for large floor spans of up to 4m
- Suitable in cyclonic regions
- Ideal for remote areas and difficult terrain
- · Backed by our technical support team
- · Independently tested to ASTM piling standards
- Green solution for low carbon footing system
- Ability to support various types of loading such as compression, uplift, lateral loads and bending moments
- Suitable in any penetrable soil such as sand, silt, clay, fine gravels and even sedimentary rock



COST SAVINGS

SUSTAINABLE

TIME SAVER

NO HEAVY EQUIPMENT QUALITYMATERIALS

"Surefoot's aim is to inform all industries that there are better, faster, cleaner and easier alternatives than using concrete."



\$250 (SF 150) Residential Bolting pattern: 140mm centres x 4 x 22mm holes 4 x 32NB (Nominal Bore) 42.40D Galvanised Pipe Light, Medium, Heavy Load capacity: Up to 100kN Average installation time: 10 minutes approx 4-WAY 3-WAY 2-WAY






\$600(SF 600) 350-400 PCD x 4 x 26mm holes 432-500 PCD x 4 x 32mm holes 16 x 32NB (Nominal Bore) 42.40D Galvanised Pipe Light, Medium, Heavy Load capacity: Up to 360kN

Average installation time: 40 minutes approx

Surefoot Load capacities are indicative and are dependent on soil type and pile embedment depth, for specification, please contact Surefoot directly.








SUREFOOT SYSTEM SIMPLE INSTALL

FULLY ADJUSTABLE





















SEMI ADJUSTABLE / WELD DIRECT


















- Housing ideal for sloping sites
- Prefabricated structures
- Modular construction
- Decking
- Pergolas
- Fencina
- Sheds
- Carports
- Shade structures/ sails
- Playground equipment
- Green building
- Temporary structures



- Deck footings
- Shade sails
- Umbrellas
- Fences
- Backyard sheds
- Light poles
- Stock yards
- Remedial work
- Retaining walls & sound barriers



























- Commercial construction
- Portal frame construction
- Concrete slab support
- Suspended floors/ slabs
- Cyclonic tie downs
- Stabilisation
- Boardwalks and jetties
- Bus shelters
- Bridges
- Winch points



- Defence industry
- Mining industry
- Energy industry
- Signage, banner & flag industry
- Communication industry
- Tethering industry
- Event industry
- Renewable energy, solar & wind farms





























CONCRETE FREE FOOTING SYSTEM

SUREFOOT SYSTEMS AUSTRALIA HEAD OFFICE

24 Quinlan Road Epping Vic 3076 +61 3 9354 4950

sales@surefoot.melbourne www.surefootfootings.com.au

AUSTRALIAN STANDARDS

AS 2870-2011 AS/NZS 4600-2005 AS/NZS 1170.2-2011 AS 2159-2009 AS 1074-1989 AS/NZS-2041.1 2011 AS/NZS-4680:2006 AS 3566.2-2002 AS 1726-1993

ASTM TESTING

ASTM 1143 ASTM 1143-81 ASTM D1143/D1143M-07 ASTM D3689 FHWASA-97-070

EUROCODE TESTING

EUROCODE EN1990 EUROCODE 1 EN1991 EUROCODE 3 EN1193 EUROCODE 7 EN14199 EN12699